

How to calculate the Clearance or Web gap for a Claytonrite Screen Rubber

A = Measurement across hole in the body from left edge to right edge

B = Measurement across glass from left edge to right edge (measure flat not over curve)

C = Clearance or Web measurement

A minus B divide by 2 = C

Example

A = 60cms - B = 40 cms - C = 10cms

60 minus 40 = 20

20 divided by 2 = 10

